



Overview of Functions and Codes (Alphabetical)

The table below lists all available functions. If these functions have been configured (contact System Support), they can be called by entering a code or pressing a function key.

Functions	Operating Steps
Accept a waiting call (camp-on)	   *  
Terminate second call, 1. Continue the call	(1x or 2x)  
Prevent automatic camp-on	     
Allow automatic camp-on	 *    
Call waiting tone on	 *   
Call waiting tone off	    
Accept call, directed	 *    Int.
Accept call, group	 *  
Adjust ring volume	(+ or -)  + - simultaneously
Adjust ring tone	(+ or -)  + - simultaneously
Answer call	
Assign station number (not for U.S.)	 *    MSN  Ext.
Associated dialing	 *    Int.  Stn No.
Associated service	 *    Int. 
Call charge assignment / account code	 *    Code  if appl.   Ext.

Functions	Operating Steps
Call forwarding on	 *  1  1  Stn No.   *  1  2  Stn No.   *  1  3  Stn No. 
Call forwarding off	 #  1 
Forward Line: On	 *  5  0  1  Trk No.  1  Stn No.   *  5  0  1  Trk No.  2  Stn No.   *  5  0  1  Trk No.  3  Stn No. 
Forward Line: Off	 #  5  0  1  Trk No. 
Call forwarding in carrier network on	 *  6  4  1  MSN  Ext.   *  6  4  2  MSN  Ext.   *  6  4  3  MSN  Ext. 
Call forwarding in carrier network off	 #  6  4  1  MSN   #  6  4  2  MSN   #  6  4  3  MSN 
Call waiting (camp-on)	  Int.  Stn busy; wait 5 seconds
Change call number	 *  9  4  1  9  own call No.  Code  #  9  4  1  9
Change call volume	 (+ or -) + - simultaneously
Changeover on (lock)	 *  6  6  Code
Changeover off (unlock)	 #  6  6  Code
Lock all phones	 *  9  4  3  Int. * 
Unlock all phones	 *  9  4  3  Int. # 
Consult	 Consultation   Stn No. 
Quit consultation, 1. Continue the call	(1x or 2x) Consultation  
Toggle	Consultation   *  2 
Start three-party conference	Consultation   *  3 
Connect parties	



Functions	Operating Steps
Control relay on	* 9 0 (1 ... 4)
Control relay off	# 9 0 (1 ... 4)
Conversation (entrance telephone)	or after 30 seconds Int.
Open door	Consultation * 6 1 Int.
Door release on	* 8 9 Int. + Code (1 or 2)
Door release off	# 8 9 Int.
DND on	* 9 7
DND off	# 9 7
DTMF dialing/Tone dialing	Consultation * 5 3
Ending a call	or Release
Group call, leave	# 8 5 or # 8 5 # or # 8 5 Group
Group call, join	* 8 5 or * 8 5 * or * 8 5 Group
Hotline	
Making calls	Stn No. or Stn No.
Monitoring (only U.S.)	* 9 4 4 Int.
Mute off	Mute
Mute on	Mute
Night answer on	* 4 4 Int. or * 4 4 *
Night answer off	# 4 4
Override	Stn busy Consultation * 6 2

Overview of Functions and Codes (Alphabetical)

Functions	Operating Steps
Paging another person (not for U.S.)	* Int.
Answer page (simple paging equipment)	* Int.
Answer page (enhanced paging equipment)	Int.
Park a call	*
Retrieve parked call	(...)
Phone test	* 0
Picking up (retrieving) a held call	* Line No.
Redial	
Reject call	
Reserve trunk	Busy (external); wait 5 seconds
When the reserved trunk is free	Ext.
Reset services	0
Ring transfer on	* 0 Line No.
Ring transfer off	0 Line No.
Ringing group on	* Int.
Ringing group off	
Room monitor on	*
Room monitor off	
Monitoring a room	Int.
Save timed reminder	* (Time, e.g. 0905)
Delete timed reminder	
Accept timed call	
Saving a PIN	* Old code 2x new code

Functions	Operating Steps
Send message	* 6 8 Int. (0...9)
Delete message (sent)	# 6 8 1
Accept message	# 6 8 3
Speaker call	* 8 0 Int.
HF answerback	
Start conference	Stn No. Consultation Stn No. Consultation * 3
The other party does not respond 1. Continue the call	(1x or 2x) Consultation
Add a party to the conference (max. five)	Consultation Stn No. Consultation * 3 etc.
Leave conference	
Remove party	Consultation # 3
Remove ISDN central office party from the conference (only for U.S.)	Consultation * 4 9 1
Store a callback	Callback
Delete callback	# 5 8
Accept callback	
Suppress caller ID on	* 8 6
Suppress caller ID off	# 8 6
Telephone data service	Consultation * 4 2
Trace call (not for U.S.)	Consultation * 8 4
Transferring a call ...after announcement to group	Consultation Stn No. Consultation * 8 0 Group
Trunk flash	Consultation * 5 1

Overview of Functions and Codes (Alphabetical)

Functions	Operating Steps
UCD	
Log on at beginning of shift	* 4 ^{int} 0 1 Code
Log off at end of shift	# 4 ^{int} 0 1
Log off work	# 4 ^{int} 0 2 ^{ext}
Log on work	* 4 ^{int} 0 2 ^{ext}
Work time on	or * 4 ^{int} 0 3 ^{ext}
Work time off	or # 4 ^{int} 0 3 ^{ext}
Night answer on	* 4 ^{int} 0 4 ^{int}
Night answer off	# 4 ^{int} 0 4 ^{int}
Use speed-dialing	Speed-dial (*0...*9 or 000...999) or
Speed-dialing: store station	* 7 ^{int} (*0...*9 or 000...999) * 9 ^{int} 2 ^{ext} *0...*9 Ext.
Using another phone temporarily	* 5 ^{int} 0 8 ^{int} Int. Code
Using mailboxes	# 6 ^{int} 8 ^{int} 3 ^{ext} or Message Waiting

